WIFI Printer Configuration Methods

Download printer setup tool via the link :
www.cnfujun.com/d/33 ｜ www.cnfujun.com/d/39
and find "Printer Tools" – Printer Setup Tool.

1-2. Select the correct port "USB" and click "Connect".

3. Select WIFI parameter settings

4. Select "AP+STA" in mode, and then click "Settings"


1

---

5. STA mode setting method:
①. DHCP: Select "static"
②. IP:Enter the IP address(Get IP information in the local area network)
③. GW: input gateway(Get GW information in the local area network)
④. Sub: Enter the subnet mask(Get Sub information in the local area network)
 (Above steps are completed, pls click the corresponding"Settings")
⑤. Name (SSID): Router WiFi Name
⑥. Network pin: WIFI password
 (Above steps are completed, pls click the corresponding"Settings")

Readme: This WiFi frequency is 2.4G and does not support 5G. WiFi settings only apply to modules with the WiFi name

2


Label Editing Software WIFI configuration method:

①.Open the label editing software and click "Config";



Print Label
Label Editing Software
Install Password:1234

②. Select the connection method: "WIFI";When using the APP for the first time, it will prompt you to obtain relevant permissions. Please click "Allow".


3

③. After entering the WIFI password, click "Start" ; Please note that before starting, be sure to let the printer enter the distribution mode:

(press the FEED button 3 times in a row, you will hear two beeps and automatic printing infomation shows that has already enter the distribution mode)

④. Please wait till to prompt that the network distribution is successful and the printer IP address is obtained; If the configuration is not successful, please check that the phone is connected to WIFI correctly and the WIFI password is entered correctly.

3. Use Android APP "Set Tools"

①. Mobile phone scan below QR code download the tool or go to APP website to download:
https://www.pgyer.com/ZQRStW

②. After installing the APP, open the app and find the "WiFi config";


③. Enter the WIFI password;

④. Click "Start" ;
Please note that before starting, be sure to let the printer enter the distribution mode:
(press the FEED button 3 times in a row, you will hear two beeps and automatic printing infomation shows that has already enter the distribution mode)

⑤. Please wait till to prompt that the network distribution is successful and the printer IP address is obtained; If the configuration is not successful, please check that the phone is connected to WIFI correctly and the WIFI password is entered correctly.